


OCEA Installation Manual

For technical support, please email support@evervue.com.
Mention your order number.




Ocea Drill-Free Wall Mount Installation


1. Attach the stainless hook pads, 2 pads on the top, 2 pads upside down on the bottom. Included in the package is a template that explains where exactly you need to position the pads. Clean the wall before applying. Included in the package are 8 additional 3M adhesive pads for relocation. Each pad is designed to hold 45LBS/20KG, and 65LBS/30KG for the larger pads.




2. Secure the wall boxes of the TV and the speaker with 6 bolts (8 bolts for larger models). Install the aluminum surface mount frame. This will be connected with built-in magnets.




3. Connect power to the Ocea. Close the cable compartment (optional: Connect RF cable, Antenna, or HDMI). You may need to add a 20'/5 meter power extension cable to locate the power supply in a safe place. This is available in our store.



4. Hang the Ocea on the wall, or mount to the bracket.



5. Turn on the TV with the remote control, or the touch on/off button. Connect the Ocea to your local Wi-Fi network.



6. You are now ready to enjoy your Ocea TV.

