


OCEA Installation Manual

For technical support, please email support@evervue.com.
Mention your order number.




Flat Wall Mount Installation


1. Install small hooks in the wall. Depending on the kind of wall, you may need to consult with a licensed installer to determine the best type of bolt/hook to use. Included in the package is a template that explains exactly where you need to position the hooks.




2. Secure the wall boxes of the TV and the speaker with 6 bolts (8 bolts for larger models). Install the aluminum surface mount frame. This will be connected with built-in magnets.




3. Connect power to the Ocea. Close the cable compartment (optional: Connect RF cable, Antenna, or HDMI). You may need to add a 20'5 meter power extension cable to locate the power supply in a safe place. This is available in our store.



4. Hang the Ocea on the wall, or mount to the bracket.



5. Turn on the TV with the remote control, or the touch on/off button. Connect the Ocea to your local Wi-Fi network.



6. You are now ready to enjoy your Ocea TV.

