


- 1 Remove the screws of the TV case and gently open it.



- 2 Remove the screws of the panel.



- 3 Open the panel and clean the dirty spots.

