


How To change Screen Orientation (4K TV System)




Installation Manual



1 Press the Source button


On the remote, find and press the "Source" button.



2 Highlight HDMI1


An input source menu would pop up at the top right portion of your screen. Highlight the HDMI1 option but do not press it.

(Note: If the HDMI1 button is accidentally pressed, press the exit button and start from the beginning.)




3 Press 2-0-0-8

Slowly press the buttons 2-0-0-8. This will prompt the design setting menu to pop up on the screen.




4 Press the USER SET

Under "Design Setting", find and press "USER SET".



5 Press Mirror Enable.

Under "USER SET", find and press "Mirror Enable".




6 Set Mirror Enable to Mirror HV

Change "Mirror Enable" to "Mirror HV". The TV screen should now be back to its normal position.

How To change Screen Orientation (4K TV System)



Installation Manual



7 Press the Exit Button

Press the "Exit" button to go back to main screen.