


# How To change Screen Orientation (HDMI TV System)




## Installation Manual




### 1 Press the Menu button

On the remote, find and press the "Menu" button.




### 2 Press 2-5-8-0

Slowly press the buttons 2-5-8-0. This will prompt the factory setting menu to pop up on the screen.




### 3 Press the SPECIAL SET

Under "Factory Setting", find and press "SPECIAL SET".




### 4 Press Panel Control

Under "SPECIAL SET", press "Panel Control".



### 5 Press Mirror Enable

Find "Mirror Enable" and set it to "ON". The TV screen should now back to normal.



### 6 Press the Exit Button

Press the "Exit" button to go back to main screen.