




Panel Orientation Instructions (HDMI TV System)




1 Press the Menu Button
On the remote, find and press the “Menu” button.
* Note: Disconnect all HDMI connections from the TV.




2 Press 2-5-8-0
Slowly press the buttons 2-5-8-0. This will prompt the factory setting menu to pop up on the screen.




3 Press the Special Set
Under the “Factory Setting”, find and press “SPECIAL SET”.



4 Press Panel Control
Under “SPECIAL SET”, find and press “Panel Control”.



5 Press Mirror Enable
Find “Mirror Enable” and set it to “ON”. The TV screen should now go back to normal.



6 Press the Exit Button
Press the “Exit” button to go back to main screen.